



AMI VIDEO UPGRADE KIT

The AMI Video Upgrade Kit lets you connect your jukebox to a nearby TV, providing access to a music television channel with thousands of music videos available on-demand. Patrons can select videos right from the jukebox alongside their favorite songs! This premium upgrade gives your jukebox a cutting-edge visual advantage that patrons can't miss and locations will love.



WHY OFFER MUSIC VIDEOS?

The AMI Video Upgrade Kit offers an exciting new revenue option for your current fleet of NGX jukeboxes.

- Video up-sell helps maximize the revenue of each transaction without getting in the way of what your jukebox is there to do – PLAY MUSIC
- Provides additional revenue with no change in music fees
- HD videos and promotional loops make your jukebox impossible to ignore
- Provides a full audio-visual experience that no other jukeboxes can match

HOW DOES IT WORK?

When selecting a song from your jukebox or the AMI Music app, patrons can pay one extra credit to have a music video accompany their song choice. A special video icon highlights which songs feature music videos.

- Thousands of music videos available - from classic hits to today's hottest artists
- Browse popular videos with the menu's Top Videos tab
- Once selected, music videos play on connected TVs
- Music video selection is restricted by the jukebox's existing Media Lockout settings
- Unwanted videos can be cancelled by your jukebox's current remote control
- Fully compatible with the AMI Music app
- Hard-wired broadband internet connection required

WHAT'S INCLUDED?

The AMI Video Upgrade Kit is available both with and without a high-performance core. See reverse side to determine which kit to purchase for your jukebox.

Both available kits include:

- 25' HDMI cable to connect jukebox to an existing television
- Video Card for core computer with HDMI output
- Additional 1TB hard drive pre-installed with thousands of music videos
- New core computer hardware to support dual drives
- Easy-to-follow installation instructions

HOW TO ORDER A KIT

AMI Video Upgrade Kits are available for NGX model jukeboxes, as well as many of AMI's other models. To determine which kit is needed for your NGX jukebox, look for the part number on the front face of the core computer.

The NGX Face Place cannot simultaneously support both music video and photo booth functionality. If you wish to permanently convert an NGX Face Place, Upgrade Kit 26695502 is needed. Contact support for additional assistance.

CORE PART NUMBER:	ORDER:
61197004	Upgrade Kit 26675501
61197001 or 61197002	Upgrade Kit 26695502
Non-NGX Model	Upgrade Kit 26695504



PROMOTE YOUR VIDEO JUKEBOX

- Make your AMI Video Jukebox stand out with a Marquee kit or Marquee Skin, available for NGX, NGX Mini, and for remote TVs.
- Table Tents and Posters are available. Contact support for details.

HOW TO INSTALL MUSIC VIDEO

It takes just a few simple steps to upgrade your location to the ultimate jukebox experience. First, power down your NGX jukebox and install the contents of the Upgrade Kit. Next, power on the TV and connect it to your jukebox using the supplied HDMI cable. Finally, power on the jukebox and enable Music Videos through Service Mode > Playback Management > Video Settings. Tune your TV to the appropriate HDMI input and you're all set!

